

However, you can simply configure the DE91 with the same properties.

28.01.2024











**DE91** 

## Measurement range





## Measurement range

D1	0 25 Pa
J6	0 50 Pa
D4	0 100 Pa
D6	0 250 Pa
J7	0 500 Pa
D9	0 1000 Pa
L5	-25 +25 Pa
L2	-50 +50 Pa
L0	-20 +80 Pa
L7	-100 +100 Pa

D1	0	 25 Pa
J6	0	 50 Pa
D4	0	 100 Pa
D5	0	 160 Pa
D6	0	 250 Pa
D7	0	 400 Pa
J7	0	 500 Pa
D8	0	 600 Pa
D9	0	 1000 Pa
L4	-12.5	 +12.5 Pa
L5	-25	 +25 Pa
L2	-50	 +50 Pa
L0	-20	 +80 Pa
L7	-100	 +100 Pa
L6	-250	 +250 Pa
L8	-1	 +1 kPa

The measuring range can easy be set to the measuring range of the DE40

## Process connection

[5.6]	(Code no.)
40	Aluminium screw connection for 6 / 4 mm hose
41	Aluminium screw connection for 8 / 6 mm hose
P6	Pneumatic plug connector for 6/4 mm hose
PR	Pneumatic plug connector for 8/6 mm hose

→	
$\rightarrow$	
→	
→	

[5,6]	
40	CK aluminum screw connection for 6/4 mm hose
41	CK aluminum screw connection for 8/6 mm hose
P6	Pneumatic plug connector MS nickel-plated for 6/4 mm hose
P8	Pneumatic plug connector MS nickel-plated for 8/6 mm hose
24	Cutting ring connection in stainless steel for 6 mm pipe
25	Cutting ring connection in stainless steel for 8 mm nine

## Output signal

ıpuı s	ignai
[7]	(Code no.)
0	without output signal
Α	0 20 mA (3-wire)
Р	4 20 mA (3-wire)
С	0 10 V (3-wire)

$\rightarrow$	0
	Α
→ → →	P
$\rightarrow$	С

[7]	Output signal
0	ohne
Switchable, factory preset:	
С	0 10 V
Α	0 20 mA
Р	4 20 mA
Digital .	interface:
M	RS485 Modbus RTU (without switching outputs)
N	RS485 Modbus RTU (with 4 switching outputs)
- 1	IO-Link (with 4 switching outputs)